

FORD SO-EZ Gasket Installation Instructions



Step 1

Before installation, be sure to clean the sealing surface areas of the pipe and the mechanical joint socket.

Step 1. Snap the SO-EZ Gasket onto the MJ gland lip. (NOTE: The Ford UFR1500 comes with the SO-EZ Gasket already attached to the gland lip.) Place MJ gland or MJ gland restraint on pipe. Insert the pipe into the MJ socket. Lubricate the SO-EZ Gasket.

Step 2. Slide the MJ gland/SO-EZ Gasket assembly along the pipe and into the MJ socket.



Step 3

Step 3. Tighten the tee bolts in an alternating manner to ANSI/AWWA C111 specifications. Use of a torque wrench is recommended.

Step 4. Tighten the actuating screws on the MJ gland to the manufacturer's specifications. Use of a torque wrench is recommended.

Step 4



The sole purpose of the snap-on lip of the SO-EZ Gasket is to maintain alignment of the gland/gasket assembly. The gasket lip will be visible after proper installation is complete, as shown in the picture to the left.

